



INSTALLATION INSTRUCTIONS FOR DOOR SILLS

Congratulations on your purchase of a high quality PUTCO product.

Should you need any application or technical assistance feel free to call us at: **1-800-247-3974**

Monday-Friday 8:00 a.m.- 5:00 p.m. (Central Standard Time)

Contact your PUTCO dealer for other quality accessories.

PUTCO Inc. - 216 West First Street - Story City, Iowa 50248

Please read all instructions before beginning installation, check to see that all parts are included.

Note: IMPORTANT!!! Temperature must be above 60 degrees F for tape to adhere properly.

Step 1: Before removing backing from tape, place item on vehicle and check for fit. The part goes on the painted surface below the factory plastic door sill.

Step 2: Clean entire area with alcohol (do not substitute with any cleaner). The area covered by the door sill must be thoroughly cleaned and free of all waxes.

Step 3: Remove backing from tape, being careful not to touch item to vehicle until properly placed. Press firmly with the palm of your hand, working from center out to insure good adhesion. Once item is in place, it cannot be removed without damage to item.

Note: PUTCO recommends applying a high quality automotive wax to maintain the original.

Feb 2005

LIMITED WARRANTY

Putco guarantees it's Stainless Steel and Aluminum products against defects in workmanship and material for as long as you own your vehicle. Black products have a 90 day warranty on the painted surface. Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco.



INSTALLATION INSTRUCTIONS FOR DOOR SILLS

Congratulations on your purchase of a high quality PUTCO product.

Should you need any application or technical assistance feel free to call us at: **1-800-247-3974**

Monday-Friday 8:00 a.m.- 5:00 p.m. (Central Standard Time)

Contact your PUTCO dealer for other quality accessories.

PUTCO Inc. - 216 West First Street - Story City, Iowa 50248

Please read all instructions before beginning installation, check to see that all parts are included.

Note: IMPORTANT!!! Temperature must be above 60 degrees F for tape to adhere properly.

Step 1: Before removing backing from tape, place item on vehicle and check for fit. The part goes on the painted surface below the factory plastic door sill.

Step 2: Clean entire area with alcohol (do not substitute with any cleaner). The area covered by the door sill must be thoroughly cleaned and free of all waxes.

Step 3: Remove backing from tape, being careful not to touch item to vehicle until properly placed. Press firmly with the palm of your hand, working from center out to insure good adhesion. Once item is in place, it cannot be removed without damage to item.

Note: PUTCO recommends applying a high quality automotive wax to maintain the original.

Feb 2005

LIMITED WARRANTY

Putco guarantees it's Stainless Steel and Aluminum products against defects in workmanship and material for as long as you own your vehicle. Black products have a 90 day warranty on the painted surface. Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco.