



INSTALLATION INSTRUCTIONS

MAKE: Ford
MODEL: Diesel Trucks
YEAR: 1999-2003
ENGINE: V8-7.3L (td)

Exhaust Adapter
46-60076

aFe recommends professional installation of our products.



Figure A



Figure B

Caution: Allow time for your vehicle to cool down prior to installation. When working on or under your vehicle proceed with caution. Exhaust systems reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation. Read Instructions prior to installation.

Refer to figure A for steps 1-4

Step 1: Remove turbo charger from the truck.

Step 2: Place the turbo on a table with the exhaust side facing up.

Step 3: Remove the seven bolts from the EBPV. Remove the EBPV from the turbo charger.

Step 4: Clean the mating surface with scotchbrite.

Refer to figure B for steps 5-6

Step 5: Install the High Flow Exhaust Adapter using the factory bolts and tighten.

Step 6: Reinstall the turbo charger back on the truck.

When installing the high flow exhaust adapter, you will not have to unplug the electrical plug from the harness.
