




# Grille Installation Instruction

Rev. 150116

Part#	GR01GEC78H	Application	03-07 Cadillac CTS – Low Bumper Stainless Steel Mesh Grille
-------	------------	-------------	---

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Mesh Grille	1	Stainless steel	4	Screws	4	6-32×2"
	2	"L" tabs	4		5	Nylon Lock Nuts	4	6-32
	3	Washers	4					

Install Notes: Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Open the hood and remove the six plastic fasteners from the top of the grille. Now reach behind the grille and remove four along the bottom and two on each end. Remove the grille.	N/A
3	Center the grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille. Be sure the bolts are through the OEM grille shell.	N/A
4	Test fit the grille in place. Install the tabs on the screws; use the nuts and the washers to secure the tabs. Do not over tighten the hardware.	N/A
5	Reinstall the black plastic cover which was removed in step 2.	N/A
6	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!