



PATENT PRODUCT


Grille Installation Instruction

Rev. 190301

Part#	<i>GR03HEC03 C/S/J</i>	Application	For 2003-2006 Chevy Silverado 1500/ 500 HD / 3500 Tow Hook Cover/1500 HD Tow Hook Cover/2003-2004 Chevy Silverado 2500 Tow Hook Cover/2007-2007 1500 /2500 HD / 3500 Tow Hook Cover Classic Style/2002-2006 Chevy Avalanche Tow Hook Cover Without Body Cladding
--------------	----------------------------	--------------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	2	Stainless steel	3	Speed Clips	6	8#
2	Counter Sunk Screws	6	8#x3/4"					

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.	
3	Center the billet grille into the opening of the factory grille shell. You need mark and drill six holes. Place the screw to the holes on the front of the grille. Be sure the screws are through the OEM grille shell.	
4	Secure billet grille using the speed clip from the back side of the OEM grille shell.	
5	Make sure the billet grille is centered and tighten the fasteners.	
6	Reinstall the black plastic cover which was removed in step 2.	
7	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.
 Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.
 We are not responsible for any damage caused by the installation. Thank you for choosing our product!