



Grille Installation Instruction

Rev. 150116

| | | | |
|-------|------------|-------------|--|
| Part# | GR03HEC04J | Application | For 2003-2006 Chevy Silverado 1500 SS |
|-------|------------|-------------|--|

| Parts List | Item | Part Name | QTY | Description | Item | Part Name | QTY | Description |
|------------|------|---------------|-----|-----------------|------|-----------|-----|-------------|
| | 1 | Billet Grille | 1 | Stainless steel | | | | |

Install Notes: Overlay Replacement Drill Cut

| Step | Description |
|------|---|
| 1 | Identify the grille & hardware with parts list. |
| 2 | Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. Remove the plastic insert in the center of the bumper cover. It is held in the opening with plastic rivet type fasteners. Do not discard these fasteners. |
| 3 | Center the insert in the bumper opening. Align the tabs on the insert to the factory mounting holes. Secure the billet insert using the factory fasteners (not all of them are needed). |
| 4 | Make sure the billet grille is centered and tighten the fasteners.but do not over-tighten. |
| 5 | Reinstall the black plastic cover which was removed in step 2. |
| 6 | Installation completed!!! |

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.
 Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.
 We are not responsible for any damage caused by the installation. Thank you for choosing our product!