



Grille Installation Instruction

Rev. 150116

Part#	GR03HFJ00J	Application	93~97 Chevy Camaro - Billet Grille
-------	------------	-------------	------------------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Stainless steel	2	Screws	4	10×1"

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	N/A
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	N/A
3	Remove the factory black center bumper insert by bending it upwards from the bottom and clipping with side cutters the bottom plastic attachment studs. Bend it another 45 degree up and clip the upper attachment studs and remove.	N/A
4	Run a line of 1/8" tape around the inside perimeter of the cavity on black it out with semi-gloss black.	N/A
5	Center the grille in the opening and mark and drill with an 1/8" bit for the holes in the four tabs.	N/A
6	Secure with the fasteners provided. Make sure the billet grille is centered and tighten the fasteners.but do not over-tighten.	N/A
7	Reinstall the black plastic cover which was removed in step 2.	N/A
8	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!