



Installation Instructions
 Front Bolt-On/Rugged Look Fender Flares
 Dodge Ram 1500/2500 (09-ON) **FF857**

Please read instructions entirely before installing this product.

Hardware Included	QTY
EXTRUSION	28.75ft

Hardware Included	QTY
ALCOHOL TOWELETTE	4

Bolt Kit Included	QTY

Ensure that both left and right hand Fender Flares suit the profile of the vehicle. Note the areas where the Fender Flares come in contact with the vehicle. NOTE: Before fitting Fender Flares remove any moldings, strips or existing flares from the wheel arch. If there is a body side molding, mark where the molding is to be cut, alternatively the Fender Flare can be cut to go around the molding. Be sure to allow enough room for the extrusion.

***PRIOR TO ANY PAINTING & INSTALLATION, PRODUCT SHOULD BE THOROUGHLY INSPECTED FOR ALL COMPONENTS LISTED ABOVE. PRODUCT SHOULD ALSO BE TEST FITTED PRIOR TO ANY PAINTING & INSTALLATION. PLEASE CONTACT EGR IF YOU HAVE ANY FITMENT QUESTIONS AND OR MISSING COMPONENTS.**



STEP 1: Clean the body areas where the Fender Flares will make contact. Use the supplied alcohol wipe.



STEP 2: Remove all factory bolts and retain for installation of Fender Flares.

For models equipped with factory fender flares, removal of factory flares is required, please consult the vehicle service manual for factory fender flare removal.

For Technical Support/Warranty Information please call 800-757-7075
EGR Inc., 4000 East Greystone Drive, Ontario, CA 91761



Installation Instructions

Front Bolt-On/Rugged Look Fender Flares

Dodge Ram 1500/2500 (09-ON)

FF857



STEP 3: Place the Fender Flare onto the vehicle and fit into the correct position following the contours of the body.



STEP 4: Reattach all bolts removed in step 2.



STEP 5: Check fitment and contour of Fender Flare to headlight housing and readjust if necessary.

For Technical Support/Warranty Information please call 800-757-7075
EGR Inc., 4000 East Greystone Drive, Ontario, CA 91761



Installation Instructions

Front Bolt-On/Rugged Look Fender Flares

Dodge Ram 1500/2500 (09-ON)

FF857

REAR FENDER FLARE INSTALLATION



STEP 6: Clean the body areas where the Fender Flares will make contact. Use the supplied alcohol wipe.



STEP 7: Remove all factory bolts and retain for installation of Fender Flares.

For models equipped with factory fender flares, removal of factory flares is required, please consult the vehicle service manual for factory fender flare removal. Place the Fender Flares on to the vehicle and fit into the correct position following the contours of the body.



STEP 8: Install all bolts removed in step 7.



STEP 16: Double check the front and rear Fender Flares to make sure all bolts are tight and clips are securely fastened. Your installation is now complete. Do not use abrasive cleaners.

For Technical Support/Warranty Information please call 800-757-7075
EGR Inc., 4000 East Greystone Drive, Ontario, CA 91761