

# HUSKY WeatherBEATER™ Custom Vehicle Floor Protection


## CARE AND USE INSTRUCTIONS

---

Thank you for selecting WeatherBeater® Floor Liners from Winfield Consumer Products. Your new front floor liners are custom molded to fit your Chevrolet Colorado or GMC Canyon. The liners are made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.** However, do not remove the factory-installed carpeting

Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liners slick.

## INSTALLATION INSTRUCTIONS FOR YOUR CHEVROLET COLORADO / GMC CANYON FRONT FLOOR LINER SET



LEFT OR DRIVER'S SIDE



RIGHT OR PASSENGER'S SIDE

TO EASE INSTALLATION OF YOUR COLORADO / CANYON FRONT LINERS, MOVE BOTH FRONT SEATS TO THEIR MOST REARWARD POSITION. ONCE YOU HAVE INSTALLED YOUR LINERS, REPOSITION THE SEATS AS DESIRED. TAKE CARE THAT DRIVER'S SIDE LINER IS ATTACHED TO THE FACTORY FLOOR MAT POSTS.