



## Installation Instructions

P/N 42721 (chrome) - P/N 42721G (bronze)

P/N 42721K (black) - P/N 42721S (silver)

### Step 1

Before you permanently install the lid, place it onto the factory air box to ensure proper fit and alignment.

### Step 2

Then clean the top of the factory air box with alcohol to remove any dirt, oil or contaminants.

### Step 3

Peel the backing film off the double sided tape. Place the lid onto the air box making sure it aligns properly and press firmly to set.

**ATTENTION:** Do not use harsh chemicals to clean covers.

If you have any difficulties or questions regarding the installation of this part, contact the Spectre Performance Technical Department by email - [Tech@spectreperformance.com](mailto:Tech@spectreperformance.com) or by phone 1-909-673-9800 Monday thru Friday 6:00am to 2:00pm PST.

