



Installation Instructions

P/N 42729 (chrome) - P/N 42729G (bronze)

P/N 42729K (black) - P/N 42729S (silver)

Step 1

Clean the top of the factory Fluid Cap Cover with rubbing alcohol to remove any dirt oil or contaminants.

Step 2

Peel the backing film off the double sided tape. Place the cap cover onto the factory cap and press firmly to set.

Note: Make sure to rotate the cover so when it is placed on top of the factory cap the 2 pieces of double sided tape adhere to the flat part of the factory cap and not the raised lettering. Then press firmly to set.

ATTENTION: Do not use harsh chemicals to clean covers.

If you have any difficulties or questions regarding the installation of this part, contact the Spectre Performance Technical Department by email - Tech@spectreperformance.com or by phone 1-909-673-9800 Monday thru Friday 6:00am to 2:00pm PST.

