



Installation Instructions

P/N 42737 (chrome) - P/N 42737G (bronze)

P/N 42737K (black) - P/N 42737S (silver)

Step 1

Before you permanently install the cover, place it onto the factory fuse box lid to ensure proper fit and alignment.

Step 2

Then clean the top of the factory fuse box lid with alcohol to remove any dirt, oil or contaminants.

Step 3

Peel the backing film off the double sided tape. Place the lid cover onto the fuse box lid making sure it aligns properly and press firmly to set.

ATTENTION: Do not use harsh chemicals to clean covers.

If you have any difficulties or questions regarding the installation of this part, contact the Spectre Performance Technical Department by email - Tech@spectreperformance.com or by phone 1-909-673-9800 Monday thru Friday 6:00am to 2:00pm PST.

