



Installation Instructions

P/N 42763 (chrome) - P/N 42763K (black)

Step 1

With vehicle completely cold, Remove coolant cap slowly and release pressure.

Step 2

Then with a pair of pliers remove tension on overflow hose clamp and remove hose.

Step 3

Place cover over reservoir and press firmly down to engage locking tabs.

Step 4

Reinstall overflow hose depressing clamp again. Then install reservoir cap.

ATTENTION: Do not use harsh chemicals to clean covers.

If you have any difficulties or questions regarding the installation of this part, contact the Spectre Performance Technical Department by email - Tech@spectreperformance.com or by phone 1-909-673-9800 Monday thru Friday 6:00am to 2:00pm PST.



WARNING

This product can expose you to a chemical or chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.