



Installation Instructions

P/N 42764 (chrome) - P/N 42764K (black)

Step 1

Place cover over shock strut and press firmly down.

ATTENTION: Do not use harsh chemicals to clean covers.

If you have any difficulties or questions regarding the installation of this part, contact the Spectre Performance Technical Department by email - Tech@spectreperformance.com or by phone 1-909-673-9800 Monday thru Friday 6:00am to 2:00pm PST.



WARNING

This product can expose you to a chemical or chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.