

SPECTRE®

Performance

Installation Instructions

P/N 42780 (chrome) - P/N 42780G (bronze)

P/N 42780K (black) - P/N 42780S (silver)

42737

Step 1

Before you permanently install the cover, place it onto the factory fuse box lid to ensure proper fit and alignment.

Step 2

Then clean the top of the factory fuse box lid with alcohol to remove any dirt, oil or contaminants.

Step 3

Peel the backing film off the double sided tape. Place the lid cover onto the fuse box lid making sure it aligns properly and press firmly to set.

42739

Step 1

Clean the top of the factory Brake Fluid Cap Cover with alcohol to remove any dirt oil or contaminants.

Step 2

Peel the backing film off the double sided tape. Place the cap cover onto the factory cap and press firmly to set.

Step 3

For all other Cap Covers, place the cap cover onto the factory cap and press firmly to install until the tabs engage fully around the stock cap.

42751

Step 1

Place one half of the handle cover on each side of the factory dipstick handle, then press firmly together until the cover clamps into place.

42753

Step 1


Remove the factory brake fluid reservoir cap.

Step 2

Place the rear of the cover onto the fluid reservoir and press down to engage the tabs onto the rear of the reservoir then press down on the front of the cover to engage the front tab onto the front of the reservoir.

ATTENTION: Do not use harsh chemicals to clean covers.

If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.

 **WARNING** This product can expose you to a chemical or chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.