



# INSTALLATION INSTRUCTIONS

2015 FORD TAURUS 3.5L | PART NO. 19111



## BILL OF MATERIALS:



1. RESONATOR ASSEMBLY
2. Y-PIPE ASSY
3. MUFFLER ASSEMBLY D/S
4. MUFFLER ASSEMBLY P/S

		<b>SHOP SUPPLIES:</b>	<b>HARDWARE KIT:</b>
WEAR SAFETY GLASSES	READ INSTRUCTIONS THOROUGHLY BEFORE INSTALLING PRODUCT	SPRAY LUBRICANT  To ease removal of existing exhaust components (especially on older vehicles) spray penetrating lubricant on all fasteners and hangers/insulators that will be loosened or removed and let soak before disassembly.	1.[3] 2.50" Clamp 2.[1] 2.25" Clamp

## MINIMUM REQUIRED TOOLS:



15mm



Hanger Tool  
(Or Pry Bar)

## **MAGNAFLOW RECOMMENDS PROFESSIONAL INSTALLATION ON ALL THEIR PRODUCTS**



**WARNING:** When working on, under, or around any vehicle exercise caution. Please allow the vehicle's exhaust system to cool before removal, as exhaust system temperatures may cause severe burns. If working without a lift always consult vehicle manual for correct lifting specifications. Always wear safety glasses and ensure a safe work area. Serious injury or death could occur if safety measures are not followed.


**ATTENTION:** Always install any supplied band or U-bolt clamps to the proper torque specifications of 40-45 ft-lbs for band clamps and 30-35 ft-lbs for U-bolt clamps. Over tightening will result in the clamp breaking and will NOT be warranted by MagnaFlow.

**MAGNAFLOW:** 22961 Arroyo Vista - Rancho Santa Margarita, CA 92688 | 1(800) 990-0905  
**Technical Support:** 1(800) 959-9226 | Email: [moreinfo@magnaflow.com](mailto:moreinfo@magnaflow.com)

# INSTALLATION INSTRUCTIONS



**Step 1.** To remove the OEM exhaust loosen the clamp located in front of the factory resonator. Next disengage all welded hangers from the rubber insulators (Do not damage or discard the rubber insulators as they will be re-used to mount the new system) and remove the exhaust from the vehicle.




**Step 2.** Begin installation of the new system by fastening the Resonator Assembly inlet to the catalytic converter using the supplied 2.25" clamp (Leave all clamps and fasteners loose for final adjustment of the complete system).



**Step 3.** Next attach the Y-Pipe Assembly to the Resonator Assembly and then the Muffler Assemblies to the Y-Pipe using the supplied 2.50" clamps. Insert hangers into rubber insulators.

## INSTALLATION INSTRUCTIONS



**Step 4.** Once a final position has been chosen for the new exhaust system, evenly tighten all clamps from front to rear using the torque specifications on page one of the instructions. Inspect all fasteners after 25-50 miles of operation and re-tighten if necessary.