



**CARB PENDING**

US Patent# US 7,263,961B2

**Recommended Air Filter Cleaning Intervals: 3000 Miles.**

**Part #'s Secret Weapon Intake : 342-117**

**Application : 2003-08 Hyundai Tiburon/ Elantra 4cyl**

**Part #'s Secret Weapon Intake : 342-118**

**Application : 2003-08 Hyundai Tiburon / Elantra V6**

**Parts List : 2 x Intake pipe / 1 x Air Filter / 1 x 10mm x 12" Hose / 2 x 3" coupler  
1 x 2.5"- 3" Coupler / 1 x Intake System Bracket kit / 4 x 3" Clamp**

**Note: Additional Parts needed when you have a Dragon Filter, 1 x 3"-3" Coupler / 2 x 3" Clamp**

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove the PCV hose from OEM intake and engine.
- 3 Unplug MAF sensor harness, remove MAF sensor from the OEM air cleaner box.
- 4 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 5 Wipe the throttlebody clean of any grease, install the 2.5-3" coupler onto throttlebody, secure with OEM clamp.
- 6 Insert Weapon\*R intake pipe into the 3" coupler on intake pipe, secure with clamp.
- 7 Insert the 3" coupler onto the end of the intake pipe, secure with clamp.
- 8 Insert the MAF sensor into the 3" coupler, secure MAF sensor with clamp.
- 9 Install the 3" coupler onto the end of the MAF sensor, secure with clamp.
- 10 Insert the 2nd intake pipe into the 3" coupler on MAF sensor, secure with clamp.
- 11 Measure the OEM PVC hose, replace with supplied 10mm hose, install from PVC port to intake pipe.
- 12 Install the Weapon\*R Hyper filter onto the end of the intake pipe.

**Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**

- 13 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 14 Install filter assembly onto the end of Weapon\*R intake pipe, secure with OEM clamp.
- 15 Install U-shaped part of intake system bracket under the clamp on air filter.
- 16 Install the rubber mounting grommet to the closest hole to the Weapon\*R air filter.
- 17 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 18 Secure with washer and nut included in bracket kit.
- 19 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 20 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 21 Place Weapon\*R CARB Sticker on a visible place in engine compartment. ( If Applicable )

**WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.**

**Note:** Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon\*R dealer you purchased this product from. We recommit to your satisfaction and safety. We recommit to your safety.



**Install the SW dual pipe on the throttle body side.**

**Dragon Intake install on 2004 Tiburon w/ air box cover not install on**

**If you have any question about this product, Please refer to our website @WWW.WEAPON-R.COM**