



CARB # D-489

Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Hyper Intake : 901-119 / Dragon Intake : 801-119**

Application : **1997 Acura CL /94-97 Accord / 95-97 Odyssey / 92-96 Prelude / 4 Cylinder**  
**(94-97 ODYSSEY 4CYL #D-489-2 ONLY)**

Parts List : 1 x Weapon\*R Intake pipe. / 1 x Weapon\*R Air Filter / 1 x 10mm x 24" Hose / 1 x 4mm x 12" Hose  
1 x 2.5"- 3" Coupler / 1 x Intake System Bracket kit / 1 x 3" Clamp / 1 x 3way Tee valve

**Note: Additional Parts needed when you have a Dragon Filter, 1 x 3"-3" Coupler / 2 x 3" Clamp**

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Remove the coolant transfer / PCV hardline from OEM intake and engine.
- 3 Mark the coolant transfer hose origins, install the 10mm hose supplied in kit to those 2 locations.
- 4 Remove OEM 4mm hose from OEM rubber intake tube and intake manifold.
- 5 Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.
- 6 Wipe the throttlebody clean of any grease, install the 2.5"-3" coupler onto throttlebody, secure with OEM clamp.
- 7 Insert the intake pipe into 2.5"-3" coupler on throttlebody, secure with supplied clamp.
- 8 Measure and cut to length the PVC & 4mm hose removed, from point of origin and to Weapon\*R intake pipe,
- 9 Install the hoses from their point of origin and onto the Weapon \*R intake pipe.
- 10 Install the Weapon\*R Hyper filter onto the end of the intake pipe.

**Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**

- 11 Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.
- 12 Install filter assembly onto the end of Weapon\*R intake pipe, secure with OEM clamp.
- 13 Install U-shaped part of intake system bracket under the clamp on air filter.
- 14 Install the rubber mounting grommet to the closest hole to the Weapon\*R air filter.
- 15 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 16 Secure with washer and nut included in bracket kit.
- 17 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 18 Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.
- 19 Place Weapon\*R CARB Sticker on a visible place in engine compartment. ( If Applicable )

**WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.**

**Note :** Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**  
Report any defective or missing parts to the authorized Weapon\*R dealer you purchased this product from.  
Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.



**Fuel Pressure regulator kit also available for this vehicle , for more info check our website.**  
**If you have any Question about this Product, Please refer to our website @ [WWW.WEAPON-R.COM](http://WWW.WEAPON-R.COM)**