



Recommended Air Filter Cleaning Intervals: 3000 Miles.

Part # 's **Hyper Intake: 901-141 / Dragon Intake: 801-141**

Application : **2002-05 ACURA RSX TYPE S**

Part # 's **Hyper Intake: 901-143 / Dragon Intake: 801-143**

Application : **2002-05 ACURA RSX**

**Parts List : 1 x Weapon\*R Intake pipe. / 1 x Weapon\*R Air Filter / 1 x 15mm x 8" Hose / 1 x 10mm x 12" hose / 1 x 2.75-3" Coupler / 1 x Intake System Bracket kit / 1 x Stainless Steel Clamp**

**Note: Additional Parts needed when you have a dragon filter, 1 x 3"-3" Adapter Hose / 2 x Stainless Steel Clamp**

- 1 Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.
- 2 Carefully disconnect the AIT sensor harness on the OEM rubber intake pipe, remove AIT sensor.
- 3 Remove the coolant transfer / 15mm PCV hardline from from OEM intake and engine.
- 4 Remove the 10mm air recirculator hose on OEM intake pipe,
- 5 Mark the coolant tranfer hose origins, install the 10mm hose supplied in kit to those 2 locations.
- 6 Remove the OEM ruber intake tube, remove the OEM air cleaner box by pulling upwards.
- 7 Wipe the throttlebody clean of any grease, install the 2.75"-3" coupler onto throttlebody, secure with OEM clamp.
- 8 Insert the Weapon\*R intake pipe into the 3" side ofcoupler and secure with clamp.
- 9 Measure and cut to length the 15mm PVC hose removed, from valve cover port and to Weapon\*R intake pipe,
- 10 Install the 10mm hose onto the Air recirculator port on engine and to the Weapon \*R intake pipe.
- 11 Insert the Weapon\*R filter into the intake pipe, secure with clamp.
- Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.**
- 12 Install the 3"-3" coupler onto the Weapon\*R intake pipe, secure with OEM clamp.
- 13 Install Dragon or Secret Weapon air filter into coupler, secure with supplied clamp.
- 14 Install U-shaped part of intake system bracket under the clamp on air filter.
- 15 Install the rubber mounting grommet to the closest hole to the Weapon\*R air filter.
- 16 Bend the straight portion of the intake system bracket to the Rubber mounting grommet.
- 17 Secure with washer and nut included in bracket kit.
- 18 Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.
- 19 Check for hood clearance, re-adjust intake
- 20 Place Weapon\*R CARB Sticker on a visible

**WARNING: EO# LABEL IS REQUIRED TO A**

Returned Products may be subject to a 25%  
Report any defective or missing parts to the  
Installation does require some mechanical s



Cold Airbox Kit available for this vehicle.

If you have any Question about this Product, Please refer to our website @ [WWW.WEAPON-R.COM](http://WWW.WEAPON-R.COM)