



Part #'s

Application :

Parts List :

1
2
3
4
5
6
7
8
9
10
11
12

13
14
15
16
17
18
19
20
21

Note:





Recommended Air Filter Cleaning Intervals 3000 Miles.

Hyper Intake : 906-112 / Dragon Intake : 806-112

1999 Subaru Forester 2.5L / Impreza 2.2L & 2.5L / 2.2L & 2.5L Legacy

note: some pre 99 models may be equipped with 98 engine application, contact our tech for pipe exchange if needed.

(1999 FORESTER/ IMPREZA/ LEGACY 2.5L #D-489-2 ONLY)

1 x Weapon*R Intake pipe. / 1 x Weapon*R Air Filter / 2 x 10mm x 24" Hose / 1 x 2.75" coupler

1 x 2.5"- 3" Coupler / 1 x Intake System Bracket kit / 3 x 3" Clamp / 1 x AFM subaru Adapter plate

Note: Additional Parts needed when you have a Dragon Filter, 1 x 3"-3" Coupler / 2 x 3" Clamp

Remove bolts securing OEM air cleaner box, loosen clamps on OEM rubber intake pipe.

Remove the PCV hoses from OEM intake and engine.

Unplug and remove the MAF sensor from the air intake system.

Remove the OEM rubber intake tube, remove the OEM air cleaner box by pulling upwards.

Wipe the throttlebody clean of any grease, install the 2.75" coupler onto throttlebody, secure with OEM clamp.

Insert Weapon*R intake pipe into the 2.75" coupler, secure with clamp.

Measure from valve cover PCV ports to Tee fitting, and from Tee fitting to intake pipe. Replace with supplied 10mm hoses.

Measure from crankcase PCV port to 10mm port on intake pipe. Replace with supplied 10mm hose.

Stretch the 2.5-3" coupler onto end of intake pipe, secure with clamp.

Insert MAF into the 2.5-3" coupler, secure with clamp, connect MAF harness.

Line up the holes on MAF to the AFM subaru adapter plate, secure with nuts and bolts in kit.

Install the Weapon*R Hyper filter onto AFM adapter plate..

Note: If your vehicle has a extra 15mm port you need 806-111-101 1990-98 Subaru

Note: Dragon / Secret Weapon Filter Option : Disregard installation on Hyper filter.

Install 3" coupler onto Dragon or Secret Weapon air filter, secure with supplied clamp.

Install filter assembly onto the AFM adapter plate, secure with OEM clamp.

Install U-shaped part of intake system bracket under the clamp on air filter.

Install the rubber mounting grommet to the closest hole to the Weapon*R air filter.

Bend the straight portion of the intake system bracket to the Rubber mounting grommet.

Secure with washer and nut included in bracket kit.

Position air intake pipe for clearance, making sure no parts are touching any part of the vehicle.

Check for hood clearance, re-adjust intake tube for perfect fitment and clearances.

Place Weapon*R CARB Sticker on a visible place in engine compartment. (If Applicable)

WARNING: EO# LABEL IS REQUIRED TO AID IN THE PASSING THE SMOG CHECK INSPECTION.

Returned Products may be subject to a 25% restocking charge. **INSTALLED PRODUCTS ARE NON-REFUNDABLE !**

Report any defective or missing parts to the authorized Weapon*R dealer you purchased this product from.

Installation does require some mechanical skills. We recommend a qualified mechanic to install this product.



Fuel Pressure regulator kit also available for this vehicle , for more info check our website.

If you have any Question about this Product, Please refer to our website @ WWW.WEAPON-R.COM

