



adarmac.com)

- Adhere to safety warnings and cautions outlined in ADARAC™ Installation Instructions (available at adarmac.com)
- Always use caution when loading or unloading cargo securely before securing cargo or operating truck
- Verify ADARAC™ and Tie Downs are mounted securely
- Always distribute weight evenly
- Use Tie Downs to secure cargo in truck box only


**SAFETY INFORMATION**

**▲ WARNING:** Each Tie Down has a maximum load capacity of 50 lbs. DO NOT EXCEED this capacity.

**TOOLS:** Protective eyewear, Phillips screwdriver, ratchet and 9/16" socket

**REQUIREMENT:** ADARAC™ Rails with mounting channels

**TIE DOWN INSTRUCTIONS**



**CONTENTS:** (4) Tie Downs, (4) Channel nuts and (4) 3/8" x 5/8" Hex bolts



TIE DOWN KIT | SET OF FOUR

- Quickly and easily secure cargo
- Freely reposition along rail
- Simple installation



Reorder #4004449

## TIE DOWN INSTALLATION

**NOTE:** If installing Tie Downs and ADARAC™ simultaneously proceed to Step C.

A. On both sides, use Phillips screwdriver to remove rear rack rail end cap retaining screws (#4 x 3/8") then pull rear end cap away to remove.

B. On both sides, use ratchet with 9/16" socket to remove rear upright assembly mounting bolts and keep for later. Leave channel nuts in channel.

C. Each Tie Down requires a channel nut, insert the desired quantity in each rack rail (with extended thread facing the rack rail).

**NOTE:** Tie Downs and uprights use the same channel nut for mounting. Typically, two channel nuts are added to each rail (to install 2 Tie Downs per rail).

D. Reinsert end cap and secure retaining screw with Phillips screwdriver.

E. Reverse Step B to reattach upright assembly to rack rails.

**NOTE:** For more information about installing an upright assembly, see ADARAC™ Installation Instructions (available at [adarac.com](http://adarac.com)).

F. Align Tie Down with channel nut then secure with bolt. Leave loose for now.

G. Slide Tie Down assembly to desired location, then fully tighten bolt using ratchet with 9/16" socket.

H. Repeat Steps F and G for remaining Tie Downs.

**IMPORTANT:** Verify Tie Downs are mounted securely before loading cargo or operating truck.

